Prysmian

A Brand of Prysmian Group

Product code – See Page 3

DESIGN & CONSTRUCTION

- A compact closure for the splicing of optical cables.
- Supplied with 24 single element trays each able to accommodate 12 splices providing a maximum capacity of 288 fibres, or 48 single circuit splice trays. Each single circuit splice tray has two storage sections providing a total of 24 trays per joint. Each tray can accommodate up to 4 splices providing a total capacity of 192 fibres.
- An input manifold manages the tubes to a common routing channel and has the provision to mount up to two optical splitters.
- The joint is for use with heat shrink splice protectors 2.2mm in diameter and 45mm in length, and 4.8mm diameter for ribbon. It can also be used with crimp splice protectors.
- The closure base has 4 circular entry ports and an oval port. Cables up to 23mm in diameter can be installed into each port. A further two small ports are available as emergency ports. These ports are for heat shrink entry and can accommodate a cable of up to 12mm in diameter.
- Circular port cables are sealed using a mechanical sealing gland. The gland can be assembled onto the cable away from the joint and is then simply plugged into the base.
- Oval port cables are sealed using adhesive lined heat shrink sleeves or using a mechanical oval port entry kit.
- Multi Way Entry Glands are available to allow the installation of a number of cables into one circular port. See page 3 for more information.
- Splice trays hinge upwards individually, allowing full access to spliced fibres without disturbance to live fibres in adjacent trays.
- Integrated loop storage basket for mid-span applications.
- Can be supplied with a pole/wall mounting bracket.
- Can be supplied with a flash test valve or a pressure relief valve. These can also be used for earthing.



Product description

The Medium Multi Function Joint (MMJ) is for jointing optical fibre cables. The joint is ideal for use as a Cable Chamber Joint, Track Joint, Spur Joint or Distribution Joint due to its capacity and compact size. It has a maximum capacity of 288 fibres. The splice trays are factory fitted and each tray can accommodate up to 12 spliced fibres. A multi-functional bracket can be supplied with the joint which enables wall or pole mounting of the joint vertically or horizontally. The joint has four circular ports for mechanical entry glands, one oval port for heat shrink or mechanical entry and two additional small circular ports also for heat shrink entry.

Prysmian

A Brand of Prysmian Group

Main characteristics

Kit Contents

The MMJ is supplied with: -

01 x Base 01 x Cap 01 x Clamp

01 x O Seal

01 x Fibre routing manifold 02 x Tube Retainer 04 x Tube Retainer Cover 01 x Loop Storage Basket Optional parts are supplied dependent on the part number selected. See page 3 for the part number table. The optional parts are: -

24 x SE or SC Trays 01 x Oval Port Entry Kit 04 x Circular Port Entry Kit 01 x Pressure Test Valve 01 x Pole / Wall Bracket Logistics

Packing Dimensions (mm):

• (I) 480 x (d) 210 x (w) 250

*Packed Weight (Kg):

2.4

*Net Weight (Kg):

1.9

* weights do not includes kits

• Minimum Fibre Bend Radius (mm):

30 (**Note**: The input manifold contains mandrels to cross fibres from one side of

the stack to the other. These are limited to 20mm radius if used).

4 circular and 1 oval (also contains 2 additional small emergency ports)

• Cable Diameter Range (mm):

• Number of Cable Ports:

• Circular Port: 4 to 23

Multi Port (in circular port):
 2.5-8.5 (4 Way), 3x2mm flat cable (8 Way), 5-9 (2 Way), 2.5-4.2mm (8 Way)

Oval Port: 7 to 21 (Heat Shrink), 5 to 14.8 (mechanical)

• Emergency Port: 4 to 12

• Cable Retention (N):

• Circular Port: > Cable (Ø/45) x 1000N with central strength member secured.

4 Way Multi Way (in circular port): > 150N for cables with Aramid yarns, > 30N for cables without Aramid yarns

• Maximum number of splice trays: 24 Single Element

24 single Circuit Double Trays (each tray has two storage area so 12 trays total)

• Maximum fibre capacity of Joint: 288 Single Element

192 Single Circuit

• Splitter capacity: 2 optical splitters of 4mm x 4mm x 60mm

• Required space envelope (mm): (I) $390 \times (w) 231 \times (d) 164$ • Operating temperature: $-40^{\circ}\text{C} \text{ to } + 70^{\circ}\text{C} \text{ (5 to } 95^{\circ}\text{RH)}$

• Material:-

Cap: GF PolypropyleneBase: GF Polypropylene

Clamp: GF NylonSplice Trays: FR ABS

• Testing:-

Closure Sealing: IP68 (5 metres) (IEC 61300-2-23)
 Optical: Tested 1310nm,1550nm and 1625nm

• Change of Temperature: IEC 61300-2-22

Dry Heat: BS EN 60068-2-2 Test Bb
 Damp Heat: IEC 60068-2-3: 1969

Vibration: IEC 61300-2-1
 Torsion: IEC 61300-2-5
 Bending: IEC 61300-2-37
 Impact: IEC 61300-2-12
 Cable Retention: IEC 61300-2-4
 Crush Resistance: IEC 61300-2-10

Prysmian Group

Linking the Future OP057-13 December 2020

Prysmian

A Brand of Prysmian Group

Part Numbers

Before creating part numbers be sure to read the information on the following pages with regards to entry kit options. Part numbers for the MMJ can be created using the configurator below. This enables the user to configure a part number so that the joint is supplied with the required input and output cable kits, valve and bracket options.

The part number is a 18 digit code built up using the information below, where:

- The first 3 letters are for the type of joint. In this case this is always MMJ.
- Next a dash is used as a separator.
- The next letter then determines the type of splice trays required.
- · Next a dash is used as a separator.
- The next letter denotes the type of oval port kit. The joint can be supplied with none (X).
- Next a dash is used as a separator.
- Then there are four letters for up to four circular port kits. The joint can be supplied with none (XXXX).
- Next a dash is used as a separator.
- The next letter denotes whether a valve (Flash Test or Pressure Relief) is required or not.
- Next a dash is used as a separator.
- The next letter denotes whether a mounting bracket (Pole/Wall or Flat) is required or not.
- Next a dash is used as a separator.
- The final letter denotes if splice protectors are required and also the type and quantity.

Example = MMJ-E-H-CMXX-X-Y-E

In the above example the MMJ would be configured with single element trays and supplied with a heat shrink oval port kit, one circular port kit for cables 7-20mm, one Multi 4 Way gland for four cable 5-7mm. The joint would be configured without a pressure test valve and supplied with a pole bracket and 2 packs of (50) splice protectors.

zMJ DA	SH TRAY	DASH	OVAL	DASH	PORT 1	PORT 2	PORT 3	PORT 4	DASH	VALVE	DASH	BRACKET	DASI	H SPLICE PROTECTOR
MMJ	- E	-	Н	-	С	M	Χ	Χ	-	Х	-	Υ	-	E
Medium Joint	SE 1.3		Heat Shrink							No Valve		Pole/₩all Bracke	t	1.3mm × 30 (PACK 50)
Select Joint Type to be supplied UMJ CMJ MMJ	Select Splice Trays to be supplied. E = SE 1.3 F = SE 2.2 C = SC 1.3 H = Crinp R = Ribbon		Select Oval Port Kit to be supplied X = None H = Heat Shrink A = Mechanical 5-7mm B = Mechanical 7-9mm C = Mechanical 11-13mm E = Mechanical 13-14.8mm A' = Mechanical 13-14.8mm C' = Mechanical 7-9mm C' = Mechanical 7-1		Port. Up to for The joint can they cambe X = None B = Single C. C = Single C. C = Single C. C = Single C. G = 2 Way G. G = 4 Way G. G = 4 Way G. G = 4 Way G. T = 4 Way G. T = 4 Way G. T = 4 Way G. W = 5 Way G. W = 5 Way G. W = 5 Way G. F = 8 Way G. G = 8 Way G. Q = 8 Way G. Q = 8 Way G. Q = 8 Way G. G = 8 Way G. G. Single C = 8 Way G. G = 8	anical Glands our glands can also be suppi ordered seper able Entry 4-7- able Entry 7-2 able Entry 7-2 able Entry 7-2 and CSM 5-9 and Aramid/C and Oval Cabl and Aramid/S and CSM 5-7- and Aramid 7- and CSM 5-7- and Aramid 7- and Aramid 2- and Aramid 2- ink Port up to 2- ink	be supplied vided without gliately at a later and safety at later and safe	vith the joint. ands and r date. lessenger o Messenger o Messenger ble and Cables		Select Valve type to be supplied X = No Valve Y = Flash Test Valve P = Pressure Relief Valv		Select Bracket to be supplied X = No Bracket Y = Pole/Wall Bracket F = Flat Bracket		X= None A= 1 pack of 12 (1.3) B= 2 packs of 12 (1.3) B= 2 packs of 12 (1.3) C= 3 packs of 12 (1.3) C= 3 packs of 12 (1.3) C= 3 packs of 50 (1.3) F= 3 packs of 50 (1.3) F= 3 packs of 50 (1.3) F= 3 packs of 50 (1.3) J= 6 packs of 50 (1.2) L= 2 pk of 12 (2.2) M= 3 pk of 12 (2.2) M= 3 pk of 50 (2.2) C= 3 pk of 50 (2.2) C= 3 pk of 50 (2.2) C= 5 pk of 50 (2.2) U= 3 pk of 50 (2.2) U= 1 pk of 50 (2.2) U= 1 pk of 50 (2.2) U= 2 pk of 50 (2.2) U= 3 pk of 50 (2.2)

Medium

Multi-function Joint - MMJ Additional Items

Prysmian

A Brand of Prysmian Group

Mechanical Cable Entry Glands

Circular port entry glands are used to install cables into one of the four ports of the MMJ base. The glands can be installed onto the cable and then simply pushed into the base of the joint. The kit contains all of the parts necessary to seal the cable and secure the strength members. Multi-way glands are available to install multiple smaller cables into one circular port. For larger cables a heat shrink port is also available (see page 5). Typical weight of a kit is



110g	Gland	No.	Min	Max	
Part Number	Туре	Entries	Cable Ø	Cable Ø	Used for
XJTSC02278	Single	1	4.0	7.0	Single cable with aramid or CSM
XJTSC01754	Single	1	7.1	20.0	Single cable with aramid or CSM
XJTSC02193	Single	1	20.1	23.0	Single cable with aramid or CSM
XJTSC02186	Dual	2	5.0	9.0	Two cables with CSM
XJTSC03320	3 Way	3	8.5	10.0	Three cables with aramid or CSM
XJTSC02872	Quad	4	2.5	4.2	Four cables with aramid
XJTSC02767	Quad	4	4.0	6.0	Four cables with CSM
XJTSC01755	Quad	4	5.0	7.0	Four cables with aramid
XJTSC02768	Quad	4	5.0	7.0	Four cables with CSM
XJTSC03287	Quad	4	6.0	6.0	Four Prysmian Ultra light weight cables upto 36f
XJTSC03148	Quad	4	7.0	8.5	Four cables with aramid
XJTSC02769	Quad	4	6.5	8.5	Four cables with CSM
XJTSC02352	Quad	4	Oval cable	s 8.5 x 5.0	Four oval cables is GRP strength members
XJTSC03135	5 Way	5	5.0	6.0	Five cables with aramid
XJTSC01878	8 Way	8	Flat drop 2.		Eight flat drop cables with a messenger wire
XJTSC02960	8 Way	8	Flat drop 2.0 messe		Eight flat drop cables without a messenger wire
XJTSC02260	8 Way	8	3.0	3.0	Eight cables with aramid
XJTSC03048	8 Way	8	2.0	3.0	Eight cables with aramid
XJTSC03049	8 Way	8	2.5	4.2	Eight cables with aramid
Prysmian Group	Linking the Futur	е	www.prysmian	group.com	OP057-13 December 2020 Page 4

Prysmian

A Brand of Prysmian Group

Additional Items Cont.

Oval Port Cable Entry Glands

Prysmian

Linking the Future

The closure is supplied with one oval port suitable for cables with a diameter range of 5.0mm to 14.8mm using mechanical seals, with heat shrink sealing the closure can be used with a diameter range of 7.0mm to 21.0mm. If you need to use with the closure with an alternative diameter cable you can order one of the kits listed below.



OP057-13 December 2020

Page 5

Part Number	Gland Type	Sealing type	Min Cable Ø	Max Cable Ø
XJTSC02028A	Oval	Mechanical	5.0	7.0
XJTSC02029A	Oval	Mechanical	7.1	9.0
XJTSC02030A	Oval	Mechanical	9.1	11.0
XJTSC02031A	Oval	Mechanical	11.1	13.0
XJTSC01896A	Oval	Mechanical	13.1	14.8
XJTSC01756	Oval	Heat shrink	7.0	21.0

Item	Prysmian Part No.	Description	Image
POLE / WALL MOUNTING BRACKET	XJTSC00136	The Pole / Wall Mounting Bracket is a universal bracket fitted to the clamp of the joint. It is used to mount the closure to a pole, wall, or wall of a footway box and allows storage in the horizontal or vertical position. Can be supplied with the joint or available as an upgrade kit.	
SUPPORT TOOL	XJTSC00075	The Support Tool allows the user to support the Joint within a portable workbench. The bracket is designed to fit most commercially available workbenches.	
FLAT MOUNTING BRACKET	XJTSC03020	The Pole / Wall Mounting Bracket is a universal bracket fitted to the clamp of the joint. It is used to mount the closure to a pole, wall, or wall of a footway box and allows storage in the horizontal or vertical position. Can be supplied with the joint or available as an upgrade kit.	Q
HEATSHRINK ENTRY	XJTSC02608	The Heat Shrink port is a mechanical port that plugs into a circular port of the LMJ base and enables a cable to be heat shrunk into the port. The port can be used for cases where larger sized cables need to be installed into the joint. The port can be used for cables up to 30mm in diameter.	

www.prysmiangroup.com

Prysmian

A Brand of Prysmian Group

Additional Items Cont.

Item	Prysmian Part No.	Description	Image
EXTERNAL TUBE FIXATION BRACKET	XJTSC02955	The External tube fixation bracket is used to offer additional retention and support to cables and tubes entering he joint. The bracket fits the outside of the joint base and is made of Stainless Steel	
EMERGENCY PORT KIT	XKTSC00401	The Emergency Port Entry Kit is used to install an additional cable into one of the two small circular ports of the joint. The kit comprises of a cable heat shrink, aluminium foil and a alcohol wipe.	
SPLITTERS	XSPSG00002 (1x4) XSPSG00003 (1x8) XSPSG00004 (1x16) XSPSG00005 (1x32)	A range of optical splitters are available to install into the joint. The splitters have 2 metre input and output legs with 900 micron G657A1 fibre. For full technical information on the splitters refer to data sheet AC005.	
SPLICE PROTECTORS 1.3	XKTSC01284 (Pack of 12) XPESC00057 (Pack of 50)	Splice protectors are used to protect the fibre splice. They are 1.3mm in diameter and 30mm in length.	
SPLICE PROTECTORS 2.2	XKTSC00050 (Pack of 12) XPESC00053 (Pack of 50)	Splice protectors are used to protect the fibre splice. They are 2.2mm in diameter and 45mm in length.	
SPLICE PROTECTORS Crimp	XKTSC00079 (Pack of 12) XKTSC00078 (Pack of 50)	Splice protectors are used to protect the fibre splice. They are 1.3mm \times 3.2mm and 30mm in length.	
GLAND SPANNER	XJTSC02320	The gland spanner is used to tighten the cable glands used for circular port entry. The spanner has a flat profile on one end and a cupped profile on the other end. The cupped profile is used to tighten or loosen a gland already installed into the joint in cases where additional cable entry is required.	
SILICONE GREASE	XBFSC00260 (Pack of 5)	Grease is used when installing a cable into one of the entry glands. A sachet of grease is supplied with each gland. The purpose of this spare tube of grease is for use adding additional cables into the 4 Way Gland at a later date.	
GLAND REMOVAL TOOL	XJTSC02964 (Pack of 10)	The Gland removal tool can be used to remove circular port entry glands from the joint base.	

Please contact your local sales office listed on www.prysmiangroup.com

[©] Prysmian Group 2020, All Rights Reserved.
The information contained within this document must not be copied, reprinted or reproduced in any form, either wholly or in part, without the written consent of Prysmian Group. The information is believed correct at the time of issue. Prysmian Group reserves the right to amend this specification without notice. This specification is not contractually valid unless specifically authorised by Prysmian Group.



Linking the Future